


KitchenAid®**CABINET PARTS**

REFRIGERATOR

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	2196094	Filler, Wrapper	28	2260507	Housing, Water Filter
	2318622	Energy Guide		2196150	White	29	4396841	Water Filter
	2318586	Owner's Manual		2196150	Biscuit	30		Cap, Water Filter
	2303925	Service Sheet		2196097	Black			
	2303929	Wiring Sheet		2315169	Apollo Gray	2260502W		White
	2220407	Modular Icemaker Service Sheet	15		Grille	2260502T		Biscuit
	2308395	Instruction Sheet, Door Removal		2303292W	White	2260502B		Black
				2303292T	Biscuit	2260502AP		Apollo Gray
				2303292B	Black	31	489500	Screw
2	2174748	Front Roller (2)	16	489497	Screw	32	3400113	Screw
3	3400517	Screw	17	489464	Screw	33	2303141	Bottom Hinge (FC)
4	2196236	Roller (Rear) (2)	18	940139	Drain Fitting	34	2260519	Block, Housing Support
5	489427	Screw	19	1108438	Extension Tube	35	2304708	Tube, Filter Outlet
6	2155013	Clip, Grille	20	1108439	Clip, Drain Tube	36	2203770	Hinge Top (FC)
7	489478	Screw	21	2188739	Cover, Unit	37	2305220	Tube, Filter Inlet
8	2156056	Shim	22		Cabinet (Not A Serviceable Part)	38		Button, Water Filter
9	2203771	Hinge Top (RC)	23		Hinge Cover	2260503W		White
11	8281227	Screw		2203408W	White	2260503T		Biscuit
12		Hinge Cover		2203408T	Biscuit	2260503B		Black
	2203407W	White		2203408B	Black	2260503AP		Apollo Gray
	2203407T	Biscuit		2203408AP	Apollo Gray	39	2223751	Door Closer, FC
	2203407B	Black	24	549193	Clamp, Service Cord	40	2305373	Clamp, Cord
	2203407AP	Apollo Gray		25	489084	Screw		
13	2304322	Bottom Hinge (RC)		26	2155311	Door Closer, RC		
				27	489483	Screw		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2255612	Escutcheon, Meat Pan Control
3	2301339	Slide Meat Pan Control
4	2257741	Louver
6	2179404	Wine Rack Asm
9	2206273	Shelf Ladder
10	489478	Screw
11	2212240	Cover, Air Diffuser
12	2301234	Door Control Asm
13	2150331	Cover, Conduit
14	2301235	Slide, Door Control
15	2216112	Air Diffuser Assembly
16	486298	Screw
18	2162085	Socket
19	2305226	Reservoir
20	2255743	Light Bulb
21	2209769	Light Lens
22	488280	Screw
23	2256035	Bracket, Dual Crisper
24	2256037	Wire Harness, Dual Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)




Illus.	Part No.	DESCRIPTION
1	2301072	Frame Assembly (2)
2	2301023	Snack Pan Asm
3	2301567	Cover, Crisper
4	2196485	Stud Assembly
5	3400894	Screw
6	2301028	Glass, Meat Cover
7	2301027	Glass, Cover
8	2301568	Cover, Meat Pan
9	2196483	Stud Assembly
10	2301031	Crisper Pan Asm (Includes 24 & 25)
11	2301026	Slide, Humidity Control
12	2301025	Knob, Humidity Control
13	2301084	Shelf and Roller Assembly (2)
14	2301022	Meat Pan Asm (Includes 25 & 26)
15	8281158	Screw
16	2301548	Glide Assembly
	2301549	Right Side
	2301115	Left Side
	2301116	Gasket, Rear
	2301126	Deflector
	2301117	Gasket, Front
	2301117	Gasket, Side (2)
21	2188212	Roller (2)
22	2301566	Shelf Assembly
24	2301001	Window, Crisper Cap, Corner
25	2301016	Right Side
	2301017	Left Side
26	2301227	Window, Meat Pan
27	2301006	Window, Snack Pan
29	2301569	Support Assembly
	2301570	Right Side
	489439	Left Side
30	489439	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)




FREEZER LINER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2301138	Top Basket
3	2198697	Gasket
4		Glide Assembly, Top Basket
	2301540	Right Side
	2301541	Left Side
6	2301139	Basket, Tall
8		Glide Assembly, Middle/Bottom Basket
	2301542	Right Side
	2301543	Left Side
11	3400893	Screw
12	2301134K	Front, Basket
14	2205837K	Shelf (2)
15	2301140	Basket, Sloped
16	8534064	Screw (12)
17	842534	Clip, Air Duct (2)
19	2198587	Cover, Emitter
22	2198635	Spring
23	2198634	Pin
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2255590	Cover, Ice Maker
28	2212321	Slide, Ice Maker Mounting
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255561	Cover, Receiver
37	2301340	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2198609	Left Side
	2198610	Right Side
46	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


MOTOR AND ICE CONTAINER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	2305336	Ice Bin
2	2305294	Crusher Bin
3	2258222	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (4)
6	2305244	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2305382	Rubber Boot
20	2305441	Latch, Bin
21	2198608	Spring, Latch
22	2187813	Wire Assembly, IDI Motor
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	2305243	Drive Shaft
32	2252130	Dispenser, Motor
33	2305208	Bracket, Motor
35	8281163	Screw
36	2212365	Sleeve, Coupling
100	2305425	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR DOOR PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #6)
	2301168W	White
	2301168T	Biscuit
	2301168B	Black
	2301168SB	Stainless Steel
	2301168SUA	Monochromatic Stainless
2	2301486	Door Compartment (Includes #15)
3	2223434K	Door Bin (4)
4	3400012	Screw
5	2219698	Stud, Handle
6		Door Gasket, Magnetic
	2221302	Mist Beige
	2221313	Black
7	2193409K	Beverage Holder
8		Handle
	2304832W	White
	2304832T	Biscuit
	2304832B	Black
	2304832SK	Stainless Steel
9	488208	Screw
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2200082	Chrome
	2200082B	Black
13		Screw
	W10010140	Chrome
	W10010150	Black
14	2165792K	Dish, Butter
15	2159124	Gasket

FREEZER DOOR PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)


Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2303516W	White
	2303516T	Biscuit
	2303516B	Black
	2303516SB	Stainless Steel
	2318451SUA	Monochromatic Stainless
2		Handle
	2304832W	White
	2304832T	Biscuit
	2304832B	Black
	2304832SK	Stainless Steel
3	2223559K	Trivet (3)
4	2219698	Stud, Handle
7	488208	Screw
8		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
9	2305474	Safety Barrier
12	2223752	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
15		Screw
	W10010140	Chrome
	W10010150	Black
17	3400012	Screw

Following Parts Not Illustrated

2310084 Wire Assembly,
Freezer Door
2305405 Tube,
Water Dispenser

DISPENSER FRONT PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	2308165	Ferrite Bead
3	2305202	Bracket, Motor
4	2305242	Connector, Door Bracket
5	2305262	Motor, Ice Door
6	2305258	Door, Ice
7	2305204	Support, Ice Door
8	4449745	Screw (2)
9	2305447	Clip, Wiring
10	2305236	Spigot
11	2305461	Seperator Assembly
12	2303843	Electronic Cover (2) Control (Core)
13	2305307CE	Pad, Water For White Model
	2305307MN	For Biscuit Model
	2305307GE	For Black and Stainless Model
	2305307AS	For Monochromatic Stainless Model
14	2305343	Lens, Front Cover
17	2305306CE	Pad, Ice For White Model
	2305306MN	For Biscuit Model
	2305306GE	For Black and Stainless Model
	2305306AS	For Monochromatic Stainless Model
18	2304140	Cover, Electronic Control
20	2303841	LED Assembly
21		Front Cover, Housing (Not Available, Order #23)
22		Drip Tray Assembly
	2315110W	White
	2315110T	Biscuit
	2315110B	Black
	2315110US	Universal Silver
23		Front Cover Assembly (Includes Items 14, 17, 18, 20, & 21)
	2305310W	White
	2305310T	Biscuit
	2305310B	Black
	2318441US	Universal Silver
24	2187814	Wire Assembly, User Interface (Includes #2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS


For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatc Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2212005	Control Box	10		Insert, Control Board (Not Available, Order #6)	20	2216115	Control Box Harness
3	3196537	Screw (4)	17	2162085	Light Socket	21	2219875	Switch
6	2304006	Electronic Control	19	2255743	Light Bulb	22	1115374	Clip, Wiring
7	8281244	Screw (4)				25	2313361	Overlay, Control Box
8	940014	Hole Plug						
9	2216879	Cover, Control Box						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	2225834	Fan, Blade	27		Drier	51	2161302	Sleeve
3	2223953	Condenser Assembly		2319825	Production	52	2172840	Wire Tie
4	489464	Screw		4387019	Service	53	489427	Screw
5	2216914	Clip, Condenser	28	2255197	Compressor (Includes Items 12, 13, 17, 27, 29, 31 & 39) (Also Order 876765 Tube Kit)	55	489478	Screw
6	2261599	Tube, Condenser to Heat Loop				59	2208280	Clip, Wire & Tube
7	2304289	Heat Shield And Drain Pan				63	2305227	Union
8	2205765	Tube Suction	29	2183454	Relay (Service Only)			
10	8533993	Screw	30	2157397	Unit Mounting Frame			
12	4387731	Cover (Service Only)	31	4387765	Wire, Capacitor (Service Only)			
13	2154697	Overload (Service Only)	32	2181929	Bracket, Fan Motor			
15	2255199	Clip, Retaining	33	2188175	Heater, Defrost			
16	2255198	Start-Device, Combination (Start Relay and Overload) for Production Compressor Only	34	2304287	Clip, Heater			
17	2169373	Capacitor	37	489373	Screw			
		Production	39		Grommet (4)			
	1118576	Service		1100826	Production			
20	2206281	Unit Cover, Bottom		4387558	Service			
21	489396	Clip	40	489340	Screw			
22	2188823	Evaporator	41	2196202	Air Baffle			
23	2161324	Clip	42	2155547	Clip, Heat			
24	2188727	Motor, Fan	48	2305374	Unit Mounting Rail			
25	1105523	Tray, Evaporator		49	8281232	Screw		
26	2187969	Harness, Unit		50	2260517	Guard, Fan		

**Following Parts Not Illustrated
and Optional Parts Not Included**

978025 Valve, Access
(1/4")
978026 Valve, Access
(5/16")
978027 Valve, Access
(3/8")
978028 Valve, Access
(1/2")
978029 Valve, Access
(5/8")
978030 Valve, Access
(3/4")
876764 Valve, Access
(3/16")

REFRIGERANT CHARGE


5.0 oz.
(R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
(White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting and Water Tube
5	628379	Clip, Fuse
10	2305225	Smart Valve
16	2305274	Clip, Tube
18	2174358	Cover
19	488649	Screw
20	2255835	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Bearing & Inlet
23	627843	Ejector
24	2198598	Ice Stripper
25	2194712	Support
26	2315522	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
29	2303583	Bracket, Ice Maker Mounting
30	489276	Screw
32	2187467	Harness, Wiring
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	626663	Icemaker Assembly

OPTIONAL PARTS

For Models: KSRT25CRWH01, KSRT25CRBT01, KSRT25CRBL01, KSRT25CRSS01, KSRT25CRMS01
 (White) (Biscuit) (Black) (Stainless Steel)(Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>			<u>PAINT, BULK (1 qt.)</u>			<u>Miscellaneous</u>		
	*350942	Primer, White		799340	Black	8129	Coil Brush	
	*350939	Black		799344	White	212643	Sealer, Gum (4 Feet)	
	*350930	White		4392900	Biscuit	479502	Tape, Vinyl (3/4 x 108")	
	*4392901	Biscuit		8171358	Graphite	505587	Sealer, Mastic (1 Qt.)	
	*8171357	Graphite				503695	Cork, Sealer (1/4 Pound)	
<u>PAINT, TOUCH-UP (1/2oz.)</u>						542638	Grease, Silicone (1/2 Oz.)	
	72017	White				542639	Cement, Alumilastic (1-1/4 Oz.)	
	4392899	Biscuit				606755	Bag, Insulation (36-5/8" x 46")	
	72032	Black				799833	Kit, Evaporator Repair (Aluminum Epoxy)	
	80051	Graphite				833938	Kit, Terminal Connector	
<u>*Important:</u> The spray paint is not to be used where the paint may make contact with the door gaskets.								
<u>ACCESSORIES</u>								
2217192 Cleaner, Stainless Steel								
<u>TORX SCREW WRENCH</u>								
1117510 Torx Key								

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST